Pneumatic Tube Fittings

XPW

MODEL(ϕ D1- ϕ D2)	
Tube(Metric)	Tube(Inch)
XPW 06-04	XPW 3/16-5/32
XPW 08-06	XPW 1/4-5/32
XPW 10-08	XPW 1/4-3/16
XPW 12-10	XPW 5/16-1/4
	XPW 3/8-5/16
	XPW 1/2-3/8

XPXJ

MODEL(ϕ D1~ ϕ D2)
Tube(Metric)
XPXJ08-06

XPXG

MODEL(ϕ D1- ϕ D2)
Tube(Metric)-Thread(R)
XPXG 08-06

XPXT

MODEL(ϕ D-T)
Tube(Metric)-Thread(R)
XPXT06-01
XPXT06-02

Pneumatic Tube Fittings With G Thread(o–ring)

XPC-G

MODEL(ϕ D-T)		
Tube(Metric)-Thread(G)		
XPC04-G01	XPC08-G02	XPC12-G02
XPC04-G02	XPC08-G03	XPC12-G03
XPC06-G01	XPC08-G04	XPC12-G04
XPC06-G02	XPC10-G01	XPC14-G03
XPC06-G03	XPC10-G02	XPC14-G04
XPC06-G04	XPC10-G03	XPC16-G03
XPC08-G01	XPC10-G04	XPC16-G04

XPL-G

MODEL(ϕ D-T)		
Tube(Metric)-Thread(G)		
XPL04-G01	XPL08-G02	XPL12-G02
XPL04-G02	XPL08-G03	XPL12-G03
XPL06-G01	XPL08-G04	XPL12-G04
XPL06-G02	XPL10-G01	XPL14-G03
XPL06-G03	XPL10-G02	XPL14-G04
XPL06-G04	XPL10-G03	XPL16-G03
XPL08-G01	XPL10-G04	XPL16-G04

XPB-G

MODEL(ϕ D-T)		
Tube(Metric)-Thread(G)		
XPB04-G01	XPB08-G02	XPB12-G02
XPB04-G02	XPB08-G03	XPB12-G03
XPB06-G01	XPB08-G04	XPB12-G04
XPB06-G02	XPB10-G01	XPB14-G03
XPB06-G03	XPB10-G02	XPB14-G04
XPB06-G04	XPB10-G03	XPB16-G03
XPB08-G01	XPB10-G04	XPB16-G04

XPD-G

MODEL(ϕ D-T)		
Tube(Metric)-Thread(G)		
XPD04-G01	XPD08-G02	XPD12-G02
XPD04-G02	XPD08-G03	XPD12-G03
XPD06-G01	XPD08-G04	XPD12-G04
XPD06-G02	XPD10-G01	XPD14-G03
XPD06-G03	XPD10-G02	XPD14-G04
XPD06-G04	XPD10-G03	XPD16-G03
XPD08-G01	XPD10-G04	XPD16-G04

XPLH-G

MODEL(ϕ D-T)	
Tube(Metric)-Thread(G)	
XPLH 04-G01	XPLH 10-G01
XPLH 04-G02	XPLH 10-G02
XPLH 06-G01	XPLH 10-G03
XPLH 06-G02	XPLH 10-G04
XPLH 06-G03	XPLH 12-G02
XPLH 06-G04	XPLH 12-G03
XPLH 08-G01	XPLH 12-G04
XPLH 08-G02	
XPLH 08-G03	
XPLH 08-G04	

XPLL-G

MODEL(ϕ D-T)	
Tube(Metric)-Thread(G)	
XPLL 04-G01	XPLL 10-G01
XPLL 04-G02	XPLL 10-G02
XPLL 06-G01	XPLL 10-G03
XPLL 06-G02	XPLL 10-G04
XPLL 06-G03	XPLL 12-G02
XPLL 06-G04	XPLL 12-G03
XPLL 08-G01	XPLL 12-G04
XPLL 08-G02	XPLL 14-G04
XPLL 08-G03	XPLL 16-G03
XPLL 08-G04	XPLL 16-G04

Pneumatic Tube Fittings With G Thread(o–ring)

XPX-G

MODEL(ϕ D-T)	
Tube(Metric)-Thread(G)	
XPX 04-G01	XPX 08-G04
XPX 04-G02	XPX 10-G01
XPX 06-G01	XPX 10-G02
XPX 06-G02	XPX 10-G03
XPX 06-G03	XPX 10-G04
XPX 06-G04	XPX 12-G02
XPX 08-G01	XPX 12-G03
XPX 08-G02	XPX 12-G04
XPX 08-G03	

XPKD-G

MODEL(ϕ D1- ϕ D2-T)
Tube(Metric)-Thread(G)
XPKD 06-04-G01
XPKD 08-04-G02
XPKD 08-06-G02
XPKD 10-08-G03

XPH-G

MODEL(ϕ D-T)	
Tube(Metric)-Thread(G)	
XPH 04-G01	XPH 10-G02
XPH 06-G01	XPH 10-G03
XPH 06-G02	XPH 12-G03
XPH 08-G01	XPH 12-G04
XPH 08-G02	
XPH 08-G03	

XPHF-G

MODEL(ϕ D-T)	
Tube(Metric)-Thread(G)	
XPHF 04-G01	XPHF 10-G02
XPHF 06-G01	XPHF 10-G03
XPHF 06-G02	XPHF 12-G03
XPHF 08-G01	XPHF 12-G04
XPHF 08-G02	
XPHF 08-G03	

XPCF-G

MODEL(ϕ D-T)	
Tube(Metric)	Tube(Inch)
XPCF 04-G01	XPCF 10-G02
XPCF 04-G02	XPCF 10-G03
XPCF 06-G01	XPCF 10-G04
XPCF 06-G02	XPCF 12-G02
XPCF 06-G03	XPCF 12-G03
XPCF 08-G01	XPCF 12-G04
XPCF 08-G02	XPCF 14-G03
XPCF 08-G03	XPCF 14-G04
XPCF 08-G04	XPCF 16-G03
XPCF 10-G01	XPCF 16-G04

XPLF-G

MODEL(ϕ D-T)	
Tube(Metric)	Tube(Inch)
XPLF 04-G01	XPLF 10-G02
XPLF 04-G02	XPLF 10-G03
XPLF 06-G01	XPLF 10-G04
XPLF 06-G02	XPLF 12-G02
XPLF 06-G03	XPLF 12-G03
XPLF 08-G01	XPLF 12-G04
XPLF 08-G02	XPLF 14-G03
XPLF 08-G03	XPLF 14-G04
XPLF 08-G04	XPLF 16-G03
XPLF 10-G01	XPLF 16-G04

XPOC-G

MODEL(ϕ D-T)	
Tube(Metric)	
XPOC 04-G01	XPOC 10-G01
XPOC 04-G02	XPOC 10-G02
XPOC 06-G01	XPOC 10-G03
XPOC 06-G02	XPOC 10-G04
XPOC 06-G03	XPOC 12-G02
XPOC 06-G04	XPOC 12-G03
XPOC 08-G01	XPOC 12-G04
XPOC 08-G02	XPOC 14-G04
XPOC 08-G03	XPOC 16-G03
XPOC 08-G04	XPOC 16-G04

XPXT-G

MODEL(ϕ D-T)
Tube(Metric)-Thread(G)
XPXT 06-G01
XPXT 06-G02

XCPC Pneumatic